


FRESH AIR KIT FOR WOOD STOVE ON LEGS AC01348


INSTALLATION INSTRUCTIONS





This manual is available for free download on the manufacturer's web site. It is a copyrighted document. Re-sale is strictly prohibited. The manufacturer may update this manual from time to time and cannot be responsible for problems, injuries, or damages arising out of the use of information contained in any manual obtained from unauthorized sources.


The kit includes:



Note: The fresh air intake must at all times come from outside the house.


Note: When installed with a fresh air kit, the stove must be anchored to the floor (see Step 13).

Items not included:




*Note: To connect to the outside, use a 5-inches diameter insulated flexible pipe (F). This HVAC type pipe must conform to ULC S110 and/or UL 181 standards and must withstand temperatures up to 250 °F.


Tools required for installation:




Step 1:




Step 2:




Step 3:







Step 5:




Step 6:




Step 7:




Step 8:




Step 9:




Step 10:





Step 11:




Step 12:







Step 13:



STOVE BUILDER INTERNATIONAL INC.

250, de Copenhague, Saint-Augustin-de-Desmaures (Quebec), Canada G3A 2H3

Tel: (418) 878-3040

Fax: (418) 878-3001